

FOR RUBBER JACKET SEALS: Push seal down over valve guide until it bottoms.

FOR SOLID OR METAL JACKET SEALS: The use of an OEM service tool is recommended. If tool is unavailable, use a deep socket or rigid tube of appropriate diameter. Center tool (or socket) over the shoulder of the seal and tap the seal down over the guide until it bottoms.

REPLACE VALVE SPRING ASSEMBLIES. Compress springs just enough to install keepers. **IMPORTANT:** Excessive compression can result in spring retainer damaging valve stem seal. Release spring carefully.

FOR RUBBER JACKET SEALS: Push seal down over valve guide until it bottoms.

FOR SOLID OR METAL JACKET SEALS: The use of an OEM service tool is recommended. If tool is unavailable, use a deep socket or rigid tube of appropriate diameter. Center tool (or socket) over the shoulder of the seal and tap the seal down over the guide until it bottoms.

REPLACE VALVE SPRING ASSEMBLIES. Compress springs just enough to install keepers. **IMPORTANT:** Excessive compression can result in spring retainer damaging valve stem seal. Release spring carefully.

FOR RUBBER JACKET SEALS: Push seal down over valve guide until it bottoms.

FOR SOLID OR METAL JACKET SEALS: The use of an OEM service tool is recommended. If tool is unavailable, use a deep socket or rigid tube of appropriate diameter. Center tool (or socket) over the shoulder of the seal and tap the seal down over the guide until it bottoms.

REPLACE VALVE SPRING ASSEMBLIES. Compress springs just enough to install keepers. **IMPORTANT:** Excessive compression can result in spring retainer damaging valve stem seal. Release spring carefully.

FOR RUBBER JACKET SEALS: Push seal down over valve guide until it bottoms.

FOR SOLID OR METAL JACKET SEALS: The use of an OEM service tool is recommended. If tool is unavailable, use a deep socket or rigid tube of appropriate diameter. Center tool (or socket) over the shoulder of the seal and tap the seal down over the guide until it bottoms.

REPLACE VALVE SPRING ASSEMBLIES. Compress springs just enough to install keepers. **IMPORTANT:** Excessive compression can result in spring retainer damaging valve stem seal. Release spring carefully.

VALVE STEM SEALS
The valve stem seals included in this set are to be used where the spring and damper assembly minimum I.D. is 1 inch.
REMOVE SPRING ASSEMBLIES, KEEPERS and the old valve stem seals.
REMOVE BURRS (IF ANY) FROM VALVE STEMS. Use a fine stone or crocus cloth. Clean stem thoroughly to remove all abrasives or dust particles. Lubricate lightly.
INSTALL NEW SEALS.
POSITIVE GUIDE SEAL: Use the plastic installation sleeve(s), included in this set, to prevent damage to the lip of the seal. Trim the plastic sleeve so it extends 1/16" below the keeper groove. Place the sleeve on the stem.
Carefully start valve stem seal over sleeve.
Remove plastic installation sleeve and reuse for installing remaining seals.
- Continued -



VALVE STEM SEALS
The valve stem seals included in this set are to be used where the spring and damper assembly minimum I.D. is 1 inch.
REMOVE SPRING ASSEMBLIES, KEEPERS and the old valve stem seals.
REMOVE BURRS (IF ANY) FROM VALVE STEMS. Use a fine stone or crocus cloth. Clean stem thoroughly to remove all abrasives or dust particles. Lubricate lightly.
INSTALL NEW SEALS.
POSITIVE GUIDE SEAL: Use the plastic installation sleeve(s), included in this set, to prevent damage to the lip of the seal. Trim the plastic sleeve so it extends 1/16" below the keeper groove. Place the sleeve on the stem.
Carefully start valve stem seal over sleeve.
Remove plastic installation sleeve and reuse for installing remaining seals.
- Continued -



VALVE STEM SEALS
The valve stem seals included in this set are to be used where the spring and damper assembly minimum I.D. is 1 inch.
REMOVE SPRING ASSEMBLIES, KEEPERS and the old valve stem seals.
REMOVE BURRS (IF ANY) FROM VALVE STEMS. Use a fine stone or crocus cloth. Clean stem thoroughly to remove all abrasives or dust particles. Lubricate lightly.
INSTALL NEW SEALS.
POSITIVE GUIDE SEAL: Use the plastic installation sleeve(s), included in this set, to prevent damage to the lip of the seal. Trim the plastic sleeve so it extends 1/16" below the keeper groove. Place the sleeve on the stem.
Carefully start valve stem seal over sleeve.
Remove plastic installation sleeve and reuse for installing remaining seals.
- Continued -



VALVE STEM SEALS
The valve stem seals included in this set are to be used where the spring and damper assembly minimum I.D. is 1 inch.
REMOVE SPRING ASSEMBLIES, KEEPERS and the old valve stem seals.
REMOVE BURRS (IF ANY) FROM VALVE STEMS. Use a fine stone or crocus cloth. Clean stem thoroughly to remove all abrasives or dust particles. Lubricate lightly.
INSTALL NEW SEALS.
POSITIVE GUIDE SEAL: Use the plastic installation sleeve(s), included in this set, to prevent damage to the lip of the seal. Trim the plastic sleeve so it extends 1/16" below the keeper groove. Place the sleeve on the stem.
Carefully start valve stem seal over sleeve.
Remove plastic installation sleeve and reuse for installing remaining seals.
- Continued -





FEL-PRO INSTALLATION TIPS

VALVE STEM SEALS

The valve stem seals included in this set are to be used where the spring and damper assembly minimum I.D. is 1 inch.

REMOVE SPRING ASSEMBLIES, KEEPERS and the old valve stem seals.

REMOVE BURRS (IF ANY) FROM VALVE STEMS. Use a fine stone or crocus cloth. Clean stem thoroughly to remove all abrasives or dust particles. Lubricatelightly.

INSTALL NEW SEALS.

POSITIVE GUIDE SEAL: Use the plastic installation sleeve(s), included in this set, to prevent damage to the lip of the seal. Trim the plastic sleeve so it extends 1/16" below the keeper groove. Place the sleeve on the stem.

Carefully start valve stem seal over sleeve.

Remove plastic installation sleeve and reuse for installing remaining seals.

- Continued -

© 2000 Fel-Pro Incorporated
Printed in U.S.A.
Form No. I-213 (Rev. 4/14)

FOR RUBBER JACKET SEALS: Push seal down over valve guide until it bottoms.

FOR SOLID OR METAL JACKET SEALS: The use of an OEM service tool is recommended. If tool is unavailable, use a deep socket or rigid tube of appropriate diameter. Center tool (or socket) over the shoulder of the seal and tap the seal down over the guide until it bottoms.

REPLACE VALVE SPRING ASSEMBLIES. Compress springs just enough to install keepers. **IMPORTANT:** Excessive compression can result in spring retainer damaging valve stem seal. Release spring carefully.



FEL-PRO INSTALLATION TIPS

VALVE STEM SEALS

The valve stem seals included in this set are to be used where the spring and damper assembly minimum I.D. is 1 inch.

REMOVE SPRING ASSEMBLIES, KEEPERS and the old valve stem seals.

REMOVE BURRS (IF ANY) FROM VALVE STEMS. Use a fine stone or crocus cloth. Clean stem thoroughly to remove all abrasives or dust particles. Lubricatelightly.

INSTALL NEW SEALS.

POSITIVE GUIDE SEAL: Use the plastic installation sleeve(s), included in this set, to prevent damage to the lip of the seal. Trim the plastic sleeve so it extends 1/16" below the keeper groove. Place the sleeve on the stem.

Carefully start valve stem seal over sleeve.

Remove plastic installation sleeve and reuse for installing remaining seals.

- Continued -

© 2000 Fel-Pro Incorporated
Printed in U.S.A.
Form No. I-213 (Rev. 4/14)

FOR RUBBER JACKET SEALS: Push seal down over valve guide until it bottoms.

FOR SOLID OR METAL JACKET SEALS: The use of an OEM service tool is recommended. If tool is unavailable, use a deep socket or rigid tube of appropriate diameter. Center tool (or socket) over the shoulder of the seal and tap the seal down over the guide until it bottoms.

REPLACE VALVE SPRING ASSEMBLIES. Compress springs just enough to install keepers. **IMPORTANT:** Excessive compression can result in spring retainer damaging valve stem seal. Release spring carefully.



FEL-PRO INSTALLATION TIPS

VALVE STEM SEALS

The valve stem seals included in this set are to be used where the spring and damper assembly minimum I.D. is 1 inch.

REMOVE SPRING ASSEMBLIES, KEEPERS and the old valve stem seals.

REMOVE BURRS (IF ANY) FROM VALVE STEMS. Use a fine stone or crocus cloth. Clean stem thoroughly to remove all abrasives or dust particles. Lubricatelightly.

INSTALL NEW SEALS.

POSITIVE GUIDE SEAL: Use the plastic installation sleeve(s), included in this set, to prevent damage to the lip of the seal. Trim the plastic sleeve so it extends 1/16" below the keeper groove. Place the sleeve on the stem.

Carefully start valve stem seal over sleeve.

Remove plastic installation sleeve and reuse for installing remaining seals.

- Continued -

© 2000 Fel-Pro Incorporated
Printed in U.S.A.
Form No. I-213 (Rev. 4/14)

FOR RUBBER JACKET SEALS: Push seal down over valve guide until it bottoms.

FOR SOLID OR METAL JACKET SEALS: The use of an OEM service tool is recommended. If tool is unavailable, use a deep socket or rigid tube of appropriate diameter. Center tool (or socket) over the shoulder of the seal and tap the seal down over the guide until it bottoms.

REPLACE VALVE SPRING ASSEMBLIES. Compress springs just enough to install keepers. **IMPORTANT:** Excessive compression can result in spring retainer damaging valve stem seal. Release spring carefully.



FEL-PRO INSTALLATION TIPS

VALVE STEM SEALS

The valve stem seals included in this set are to be used where the spring and damper assembly minimum I.D. is 1 inch.

REMOVE SPRING ASSEMBLIES, KEEPERS and the old valve stem seals.

REMOVE BURRS (IF ANY) FROM VALVE STEMS. Use a fine stone or crocus cloth. Clean stem thoroughly to remove all abrasives or dust particles. Lubricatelightly.

INSTALL NEW SEALS.

POSITIVE GUIDE SEAL: Use the plastic installation sleeve(s), included in this set, to prevent damage to the lip of the seal. Trim the plastic sleeve so it extends 1/16" below the keeper groove. Place the sleeve on the stem.

Carefully start valve stem seal over sleeve.

Remove plastic installation sleeve and reuse for installing remaining seals.

- Continued -

© 2000 Fel-Pro Incorporated
Printed in U.S.A.
Form No. I-213 (Rev. 4/14)

FOR RUBBER JACKET SEALS: Push seal down over valve guide until it bottoms.

FOR SOLID OR METAL JACKET SEALS: The use of an OEM service tool is recommended. If tool is unavailable, use a deep socket or rigid tube of appropriate diameter. Center tool (or socket) over the shoulder of the seal and tap the seal down over the guide until it bottoms.

REPLACE VALVE SPRING ASSEMBLIES. Compress springs just enough to install keepers. **IMPORTANT:** Excessive compression can result in spring retainer damaging valve stem seal. Release spring carefully.