



FEL-PRO INSTALLATION TIPS

Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

GENERAL INSTRUCTIONS

CLEAN MATING SURFACES of all foreign material. Use a degreaser.

CLEAN THREADS of bolts/studs using a wire brush; all nuts/threaded holes use a bottoming tap.

Determine Which Bolts extend into the coolant passages. Those **entering** the coolant passages require a pliable non-hardening sealer on the bolt threads and the underside of the bolt head. Those **not entering** the coolant passages require oil on the bolt threads and underside of the bolt head.

Exhaust Assembly: Apply a high temperature anti-seize lubricant to the threadings.

CHECK ALL CASTINGS for flatness; straighten, resurface or replace if out of flat conditions exists.

FINAL ASSEMBLY always requires torquing of fasteners according to OEM specifications. For certain assemblies we have provided specific torquing specifications.

Some procedures may be repeated with additional specific information for your application.

WATER PUMP GASKET

TO ASSIST IN ALIGNMENT AND SEALING DURING ASSEMBLY, apply a thin coat of gasket sealer, to both sides of gasket(s).

ROTATING SHAFT SEALS


PRIOR TO INSTALLING THE ROTATING SHAFT AND/OR SEAL apply a thin coat of lubricant, such as grease, on the sealing lip and shaft.

IMPORTANT: Do not install any seal without break-in lubricant protection.

REAR MAIN BEARING SEAL

REMOVE NICKS AND SCRATCHES (IF ANY) FROM THE CRANKSHAFT SEALING SURFACE using a crocus cloth.

INSTALL NEW SEAL(S):



PRIOR TO INSTALLING THE REAR MAIN BEARING CAP apply an anaerobic sealant to either the rear main bearing cap or cylinder block mating surfaces. **Never** apply sealant on the ends of the seals.

LUBRICATE SURFACE of seal lip and crankshaft by applying a thin coat of motor oil or grease. If engine will not be started within several days, grease is recommended.

IMPORTANT: Never install any seal without break-in lubricant protection.

INSTALL SEAL into the cylinder block. The seal is properly installed when its largest raised sealing lip is toward the **front** of the engine. (Seals with a metal garter spring require the spring to face towards the **front** of the engine.)

TEST RUN ENGINE. Check all mating areas thoroughly to determine that all seals hold during the operation.



FEL-PRO INSTALLATION TIPS

Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

GENERAL INSTRUCTIONS

CLEAN MATING SURFACES of all foreign material. Use a degreaser.

CLEAN THREADS of bolts/studs using a wire brush; all nuts/threaded holes use a bottoming tap.

Determine Which Bolts extend into the coolant passages. Those **entering** the coolant passages require a pliable non-hardening sealer on the bolt threads and the underside of the bolt head. Those **not entering** the coolant passages require oil on the bolt threads and underside of the bolt head.

Exhaust Assembly: Apply a high temperature anti-seize lubricant to the threadings.

CHECK ALL CASTINGS for flatness; straighten, resurface or replace if out of flat conditions exists.

FINAL ASSEMBLY always requires torquing of fasteners according to OEM specifications. For certain assemblies we have provided specific torquing specifications.

Some procedures may be repeated with additional specific information for your application.

WATER PUMP GASKET

TO ASSIST IN ALIGNMENT AND SEALING DURING ASSEMBLY, apply a thin coat of gasket sealer, to both sides of gasket(s).

ROTATING SHAFT SEALS


PRIOR TO INSTALLING THE ROTATING SHAFT AND/OR SEAL apply a thin coat of lubricant, such as grease, on the sealing lip and shaft.

IMPORTANT: Do not install any seal without break-in lubricant protection.

REAR MAIN BEARING SEAL

REMOVE NICKS AND SCRATCHES (IF ANY) FROM THE CRANKSHAFT SEALING SURFACE using a crocus cloth.

INSTALL NEW SEAL(S):



PRIOR TO INSTALLING THE REAR MAIN BEARING CAP apply an anaerobic sealant to either the rear main bearing cap or cylinder block mating surfaces. **Never** apply sealant on the ends of the seals.

LUBRICATE SURFACE of seal lip and crankshaft by applying a thin coat of motor oil or grease. If engine will not be started within several days, grease is recommended.

IMPORTANT: Never install any seal without break-in lubricant protection.

INSTALL SEAL into the cylinder block. The seal is properly installed when its largest raised sealing lip is toward the **front** of the engine. (Seals with a metal garter spring require the spring to face towards the **front** of the engine.)

TEST RUN ENGINE. Check all mating areas thoroughly to determine that all seals hold during the operation.