

Spark plug tube seal installation.

In order to properly install the provided spark plug tube seals the following procedure must be adhered to.

Place valve cover upside down on workbench or suitable work surface.

Press fit spark plug tube seals into each of four locations.

White lithium grease may be applied to the seal I.D. in order to ease installation.

Place valve cover in proper position on cylinder head and using a small flat tip screwdriver or blunt pick encircle each seal where it interfaces with the tube in order to "Start" the seal.

Once all four seals have been "Started" apply even downward pressure on the valve cover until it bottoms out on the top edge of the cylinder head.

Complete installation; torque fasteners to manufacturer's specifications.

Spark plug tube seal installation.

In order to properly install the provided spark plug tube seals the following procedure must be adhered to.

Place valve cover upside down on workbench or suitable work surface.

Press fit spark plug tube seals into each of four locations.

White lithium grease may be applied to the seal I.D. in order to ease installation.

Place valve cover in proper position on cylinder head and using a small flat tip screwdriver or blunt pick encircle each seal where it interfaces with the tube in order to "Start" the seal.

Once all four seals have been "Started" apply even downward pressure on the valve cover until it bottoms out on the top edge of the cylinder head.

Complete installation; torque fasteners to manufacturer's specifications.

Spark plug tube seal installation.

In order to properly install the provided spark plug tube seals the following procedure must be adhered to.

Place valve cover upside down on workbench or suitable work surface.

Press fit spark plug tube seals into each of four locations.

White lithium grease may be applied to the seal I.D. in order to ease installation.

Place valve cover in proper position on cylinder head and using a small flat tip screwdriver or blunt pick encircle each seal where it interfaces with the tube in order to "Start" the seal.

Once all four seals have been "Started" apply even downward pressure on the valve cover until it bottoms out on the top edge of the cylinder head.

Complete installation; torque fasteners to manufacturer's specifications.

Spark plug tube seal installation.

In order to properly install the provided spark plug tube seals the following procedure must be adhered to.

Place valve cover upside down on workbench or suitable work surface.

Press fit spark plug tube seals into each of four locations.

White lithium grease may be applied to the seal I.D. in order to ease installation.

Place valve cover in proper position on cylinder head and using a small flat tip screwdriver or blunt pick encircle each seal where it interfaces with the tube in order to "Start" the seal.

Once all four seals have been "Started" apply even downward pressure on the valve cover until it bottoms out on the top edge of the cylinder head.

Complete installation; torque fasteners to manufacturer's specifications.