



FEL-PRO INSTALLATION TIPS


Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

VALVE COVER GASKET

This set contains 1 molded rubber valve cover gasket and 1 cork-rubber valve cover gasket. Use the molded rubber gasket with the cast aluminum valve cover; use the cork-rubber gasket with the stamped steel valve cover.

CLEAN MATING SURFACES of all foreign material including old gaskets, RTV and oil. You may wish to use a degreaser. Also, clean oil return holes.

CHECK COVER FLANGES for flatness. Straighten stamped metal covers. Replace if severely distorted. Distorted cast aluminum or plastic covers are difficult to straighten and should be replaced.



ATTACH AND ALIGN GASKET TO COVER. Apply quick-drying adhesive sparingly in several places on the mating surface of cover. If gasket has installation tabs, adhesive is **not** required. Mount gasket on cover. **Allow time for adhesive to set.** Test for slippage with light pressure. If gasket moves, allow more time.

REINSTALL VALVE COVER TO ENGINE. Torque securely to OEM specifications. Over-torquing can distort cover and cause leakage.

TEST RUN ENGINE. Check all mating areas thoroughly to determine that all seals hold during operation.

© 2007 Federal-Mogul Corporation
Form No. I-1268 (Rev. 4/07)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS


Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

VALVE COVER GASKET

This set contains 1 molded rubber valve cover gasket and 1 cork-rubber valve cover gasket. Use the molded rubber gasket with the cast aluminum valve cover; use the cork-rubber gasket with the stamped steel valve cover.

CLEAN MATING SURFACES of all foreign material including old gaskets, RTV and oil. You may wish to use a degreaser. Also, clean oil return holes.

CHECK COVER FLANGES for flatness. Straighten stamped metal covers. Replace if severely distorted. Distorted cast aluminum or plastic covers are difficult to straighten and should be replaced.



ATTACH AND ALIGN GASKET TO COVER. Apply quick-drying adhesive sparingly in several places on the mating surface of cover. If gasket has installation tabs, adhesive is **not** required. Mount gasket on cover. **Allow time for adhesive to set.** Test for slippage with light pressure. If gasket moves, allow more time.

REINSTALL VALVE COVER TO ENGINE. Torque securely to OEM specifications. Over-torquing can distort cover and cause leakage.

TEST RUN ENGINE. Check all mating areas thoroughly to determine that all seals hold during operation.

© 2007 Federal-Mogul Corporation
Form No. I-1268 (Rev. 4/07)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS


Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

VALVE COVER GASKET

This set contains 1 molded rubber valve cover gasket and 1 cork-rubber valve cover gasket. Use the molded rubber gasket with the cast aluminum valve cover; use the cork-rubber gasket with the stamped steel valve cover.

CLEAN MATING SURFACES of all foreign material including old gaskets, RTV and oil. You may wish to use a degreaser. Also, clean oil return holes.

CHECK COVER FLANGES for flatness. Straighten stamped metal covers. Replace if severely distorted. Distorted cast aluminum or plastic covers are difficult to straighten and should be replaced.



ATTACH AND ALIGN GASKET TO COVER. Apply quick-drying adhesive sparingly in several places on the mating surface of cover. If gasket has installation tabs, adhesive is **not** required. Mount gasket on cover. **Allow time for adhesive to set.** Test for slippage with light pressure. If gasket moves, allow more time.

REINSTALL VALVE COVER TO ENGINE. Torque securely to OEM specifications. Over-torquing can distort cover and cause leakage.

TEST RUN ENGINE. Check all mating areas thoroughly to determine that all seals hold during operation.

© 2007 Federal-Mogul Corporation
Form No. I-1268 (Rev. 4/07)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS


Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

VALVE COVER GASKET

This set contains 1 molded rubber valve cover gasket and 1 cork-rubber valve cover gasket. Use the molded rubber gasket with the cast aluminum valve cover; use the cork-rubber gasket with the stamped steel valve cover.

CLEAN MATING SURFACES of all foreign material including old gaskets, RTV and oil. You may wish to use a degreaser. Also, clean oil return holes.

CHECK COVER FLANGES for flatness. Straighten stamped metal covers. Replace if severely distorted. Distorted cast aluminum or plastic covers are difficult to straighten and should be replaced.



ATTACH AND ALIGN GASKET TO COVER. Apply quick-drying adhesive sparingly in several places on the mating surface of cover. If gasket has installation tabs, adhesive is **not** required. Mount gasket on cover. **Allow time for adhesive to set.** Test for slippage with light pressure. If gasket moves, allow more time.

REINSTALL VALVE COVER TO ENGINE. Torque securely to OEM specifications. Over-torquing can distort cover and cause leakage.

TEST RUN ENGINE. Check all mating areas thoroughly to determine that all seals hold during operation.

© 2007 Federal-Mogul Corporation
Form No. I-1268 (Rev. 4/07)

Printed in U.S.A.