

# ***Installation Instructions***

## **BLF Injection Molded Bolts**

|                                |     |
|--------------------------------|-----|
| Bolt Kit Included              | QTY |
| Extruded Plastic Nuts (Chrome) | 42  |

Ensure that both left- and right-hand front Fender Flares suit the profile of the vehicle. Note the areas where the Fender Flares contacts the vehicle. NOTE: Before fitting Fender Flares remove any moldings, strips or existing flares from the wheel arch. If there is a body side molding, mark where the molding is to be cut, alternatively the Fender Flare can be cut to go around the molding. Be sure to allow enough room for the extrusion. **No drilling of vehicle is required for Bolt-On Look Fender Flares. This is a non-drill product.**



## **Attach the extruded plastic bolts.**

Step 1: Peel back a white tape liner from the bottom side of the extruded plastic bolt and press until it snaps into place.

**\*\*** Ensure the inside of Fender Flares where the rubber seal is attached is clean, using the alcohol wipes provided.

Step 2: Wipe away any residue with dry clean cloth.