



INS 2541

3060 PERFORMANCE CIRCLE
DELAND, FL 32724

PHONE: 386.624.0025
E-MAIL: tech@bbkperformance.com

INSTALLATION INSTRUCTIONS

SUBFRAME CONNECTORS / JACK RAIL SET

PART #2541

VEHICLE FITMENT:

2015-2023 Ford Mustang S550

WILL NOT Fit Convertibles



TOOLS NEEDED: Socket Wrench, 15mm Socket, Razor Blade



INSTALLATION TIME: Aproximately 15 minutes



DIFFICULTY RATING: Easy



IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK accepts no responsibility for injuries or damage cause by or during the installation of this product.



UPDATED: SEPT 2024

WWW.BBKPERFORMANCE.COM



INSTALLATION INSTRUCTIONS

PART #2541 - 2015-2023 Ford Mustang S550 - Subframe Connector / Jack Rail Set - DOES NOT FIT CONVERTIBLES

- 1** Start by jacking up the car and support using jackstands at the proper jack points.
- 2** Remove the factory bolts with a 15mm socket. Note - Using a razor blade, you may need to carefully trim back some of the body sealant for the BBK jack rail to sit flat against the body.
- 3** With the jack rails side by side, notice one is longer than the other. The longer jack rail will be mounted on the DRIVER SIDE, the shorter rail goes onto the PASSENGER SIDE.
- 4** Using the stock factory hardware, mount each of the rails on their respective side of the vehicle. Again, trim any body sealant to help keep the jack rails flush to the bottom of the body.

