



Installation Instructions

Replacement Fender Flare Trim
For EGR Rugged, Bolt-on, Summit, and OEM+ Series Fender Flares

Important: Please read instructions entirely before installing this product.

Hardware Included	QTY
Extrusion	29 ft
Alcohol wipe	4



STEP 1:
Attach the included rubber seal to the Fender Flares. Peel back 2" of the adhesive backing and position on the Fender Flare. Attach the seal to the Fender Flare, peeling back a few inches at a time. Ensure pressure is used to secure rubber seal to Fender Flare edge. Attach rubber seal along the top leading edge of the Fender Flare where it contacts the vehicle body.



STEP 2:
Pulling the extrusion liner at a right angle, remove the liner from the extrusion in small portions and apply thumb pressure to ensure that it adheres to the Fender Flares.



STEP 3:
Trim any unnecessary extrusion and discard.