



2023+ Ineos Grenadier Installation Instructions









Manufacturer warranty covers material defects on new, never installed parts. Once installed, all replacement part costs are the responsibility of the vehicle owner. Caution against blind spots during parking. Avoid curbs and excessive compression to flaps. **Check for sufficient exhaust, wheel, suspension clearances.**

INSTALLATION QUESTION? FOR REPLACEMENT PART QUOTES, SEND FLAP RECEIPT OR PHOTO → www.rallyarmor.com/support

Recommended Tools 10mm/11mm wrench, Phillips screwdriver, Pick.

Install on even surface using hand tools, not powered tools. AVOID OVERTIGHTENING HARDWARE.

ABOUT OUR STANDARD IN MUD FLAPS Polyurethane is a high grade plastic that may feature minor surface layer mark. These are visual variations that don't affect flap construction or performance. Most matte away as the material ages.

CONFIRM PARTS & QUANTITIES BEFORE INSTALLATION			
MUD FLAP KIT PN MF143 SEE PAGE 3		PART DESCRIPTION	QUANTITY
MF143-FRT-TOP		FRONT TOP	2
MF131-LT-BOT		LEFT BOTTOM	2
MF131-RT-BOT		RIGHT BOTTOM	2
MF143-RE-TOP		REAR TOP	2
HARDWARE KIT PN HMF143			
BLKNUT		NUT	16
HXBLT		BOLT	16
M6SSBLK		SCREW	14
SMWASH		WASHER	46

Do not fully tighten fasteners until flaps are aligned to vehicle.

FRONT FLAP Access interior wheel well by turning steering wheel towards the installation side.

Parts x 1 Flap → 4 x BLKNUT; 4 x HXBLT; 2 x M6SSBLK; 10 x SMWASH


IMAGE A Remove factory splash guard and fasteners 1 & 2. Temporarily remove/retain fasteners 3 - 5.

IMAGE B Assemble MF143-FRT-TOP & MF131-LT/RT-BOT flaps using SMWASH & HXBLT on logo-side and SMWASH & BLKNUT on tire-side.

IMAGE C Place logo-side of flap facing rear bumper. Install M6SSBLK & SMWASH into mounts 1 & 2. Reinstall factory fasteners into mounts 3 - 5.




2023+ Ineos Grenadier Installation Instructions



IMAGES D/E For vehicles equipped with larger offset tire & wheel combinations, check clearance by turning wheel. To add clearance, use a heat gun to warm MF131-LT/RT-BOT flap across the area shown in red. Push/hold flap towards liner until it cools and sets further away from tire.

IMAGE F Align flap to vehicle before tightening fasteners.



REAR FLAP Parts x 1 Flap → 4 x BLKNUT; 4 x HXBLT; 5 x M6SSBLK; 13 x SMWASH



IMAGE G Uninstall fasteners 1 – 5 and factory splash guards.

IMAGE H Assemble MF143-RE-TOP & MF131-LT/RT-BOT flaps using SMWASH & HXBLT on logo-side and SMWASH & BLKNUT on tire-side.

IMAGE I install SMWASH & M6SSBLK through mounts 1 - 5. Align flap before tightening fasteners until just seated.



2023+ Ineos Grenadier Installation Instructions



MF143 MOUNTING DIAGRAM

