



FEL-PRO INSTALLATION TIPS

TURBOCHARGE FLANGE BOLTS

CLEAN ALL THREADS by using a wire brush for bolts and/or studs. Apply a high temperature anti-seize lubricant to the bolt and/or stud threads.

© 2007 Federal-Mogul Corporation
Form No. I-1340 (Rev. 02/93)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

TURBOCHARGE FLANGE BOLTS

CLEAN ALL THREADS by using a wire brush for bolts and/or studs. Apply a high temperature anti-seize lubricant to the bolt and/or stud threads.

© 2007 Federal-Mogul Corporation
Form No. I-1340 (Rev. 02/93)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

TURBOCHARGE FLANGE BOLTS

CLEAN ALL THREADS by using a wire brush for bolts and/or studs. Apply a high temperature anti-seize lubricant to the bolt and/or stud threads.

© 2007 Federal-Mogul Corporation
Form No. I-1340 (Rev. 02/93)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

TURBOCHARGE FLANGE BOLTS

CLEAN ALL THREADS by using a wire brush for bolts and/or studs. Apply a high temperature anti-seize lubricant to the bolt and/or stud threads.

© 2007 Federal-Mogul Corporation
Form No. I-1340 (Rev. 02/93)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

TURBOCHARGE FLANGE BOLTS

CLEAN ALL THREADS by using a wire brush for bolts and/or studs. Apply a high temperature anti-seize lubricant to the bolt and/or stud threads.

© 2007 Federal-Mogul Corporation
Form No. I-1340 (Rev. 02/93)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

TURBOCHARGE FLANGE BOLTS

CLEAN ALL THREADS by using a wire brush for bolts and/or studs. Apply a high temperature anti-seize lubricant to the bolt and/or stud threads.

© 2007 Federal-Mogul Corporation
Form No. I-1340 (Rev. 02/93)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

TURBOCHARGE FLANGE BOLTS

CLEAN ALL THREADS by using a wire brush for bolts and/or studs. Apply a high temperature anti-seize lubricant to the bolt and/or stud threads.

© 2007 Federal-Mogul Corporation
Form No. I-1340 (Rev. 02/93)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

TURBOCHARGE FLANGE BOLTS

CLEAN ALL THREADS by using a wire brush for bolts and/or studs. Apply a high temperature anti-seize lubricant to the bolt and/or stud threads.

© 2007 Federal-Mogul Corporation
Form No. I-1340 (Rev. 02/93)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

TURBOCHARGE FLANGE BOLTS

CLEAN ALL THREADS by using a wire brush for bolts and/or studs. Apply a high temperature anti-seize lubricant to the bolt and/or stud threads.

© 2007 Federal-Mogul Corporation
Form No. I-1340 (Rev. 02/93)

Printed in U.S.A.