



advanced FLOW engineering

Instruction Manual P/N: 46-39117

92mm Throttle Body for Chevrolet & Pontiac Vehicles

Camaro SS	10-15	Camaro Z28	14-15
Caprice PPV	11-17	Corvette	09-13
Corvette ZR1	09-13	Corvette Z06	09-13
SS	14-17	Pontiac G8	09-09



Qty.	Part Description
1	92mm Throttle Body

- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- For technical support please call 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Ensure that your vehicle is cooled off before proceeding.
- Retain factory parts for future use.

1. Disconnect the negative battery terminal.
2. Remove the air intake tube from the vehicle following the manufacturer's recommended procedure.
3. Disconnect the electrical connector from the factory throttle body.
4. Remove the four (4) screws securing the factory throttle body.
5. Carefully remove the factory throttle body from the intake manifold/supercharger.
6. Clean the gasket surface on the intake manifold/supercharger. Replace the gasket if necessary (*gasket not supplied*).
7. Install the supplied aFe 92mm Throttle Body. Use the four (4) factory screws removed in Step 4. Torque to factory specifications: 10 Nm (89 in-lbs).
8. Reconnect the electrical connector to the aFe 92mm Throttle Body.
9. Reinstall the air intake tube following the manufacturer's recommended procedure.
10. Reconnect the negative battery terminal.
11. Installation is now complete.

NOTE: Check all screws, clamps, and connectors are secure after 100-200 miles