Toyota Tundra 07-21 2wd/4wd Long-Travel Kit [CAM-310018-U]

Bushing Upper Arm Hardware (1 Left Arm / 1 Right Arm)

8	Upper Arm Bushings (#2587)
4	Inner Pivot Sleeves (#1510.592.39)
8	Large plated Washers (#970415)
4	90 Degree Zerk Fittings (Self Tapping)
4	Grease Packets
2	M16 x 1.50 Nyloc Nuts
4	10-32 x 3/4" Steel SHCS Bolts
4	10-32 Steel Nyloc Nuts
8	10-32 Stainless Washers
4	ABS Wire Rubber Clamps
2	9/16-18 x 4" 12pt Bolts
2	9/16-18 Stover Nuts
2	9/16 SAE G8 Washers
2	1.50" x 9/16" Recessed Uniball Spacers (top) (#960096)
2	1.50" x 9/16" Tapered Uniball Spindle Spacers (bottom) (#960047)

Lower Arm Hardware (1 Left Arm / 1 Right Arm)

4	Inner Pivot Uniball Spacers (Long | Rear Mount) (#960053)
4	Inner Pivot Uniball Spacers (Short | Front Mount) (#960052)
4	1/2-13 x 2.75" G8 Bolts
4	1/2 SAE G8 Washers
2	12/-13 Stover Nuts

Misc. Hardware & Components

2	1.50" LCA Uniball Spindle Adaptors
4	M18 x 1.50 x 40mm Hex Bolts
4	M18 Round Washers
2	1.50" x 3/4" Recessed Uniball Spacers (top) (#960055)
2	1.50" x 3/4" Mis-alignment Uniball Spacers (bottom) (#960001)
2	MS21250-12048 3/4" 12pt Bolts
4	3/4 SAE G8 Washers
2	3/4-16 CAD Stover Nuts
2	12" Limit Straps
2	Limit Strap Frame Tabs
4	1/2-13 x 1.25" G8 Bolts
8	1/2" SAE G8 Washers
4	1/2-13 Stover Nuts
1	Extended Front Brake Line Kit (#330004)
2	Steering Extensions (#960093)
2	Upper Coilover Mounting Plates
2	1/2-13 x 4.5" G8 Bolts
4	1/2" SAE G8 Washers
2	1/2-13 Stover Nuts
8	3/8-24 x 1" G8 Bolts
16	3/8" SAE G8 Washers
8	3/8-24 Stover Nuts
4	8.5" Camburg Stickers

Notes:

1) When installing lower arm spindle uniball adaptors, make sure the snap ring is facing up and spacers are fully seated into the arm prior to tightening.
2) Use red loctite on all spindle adaptor bolts and nuts. Torque to 260 ft/lbs.
3) We recommend running a 35"-37" tire on either a 17" or 18" rim with a maximum backspacing of 4.75"
4) We recommend using a 18" x 800# lower coil and 4" x 500# upper coil on the custom spec FOX/King 2.5 x 8" travel shocks. Shocks must have a 90 degree fitting on the top cap, a flat lower spring seat and 1.25" shock spacers on top and 1.50" shock spacers on the bottom.
5) We recommend using 2.0 x 2"-2.5" bumpstops.
6) Fiberglass front fenders are required.