


# 2020+ BMW M3/M4 and Toyota Supra X3 Fuel Pump Module Plumbing Diagram - CPE, Port Injection



## Part Number Guide

### Fuel System Components

|                  |                     |
|------------------|---------------------|
| A. 9-xxx-7080    | X3 Module           |
| B. 8-03-110-010K | DWFF110 Fuel Filter |
| C. 6-1000-FRB    | DWR1000 AFPR        |
| D. 6-01-G        | Fuel Pressure Gauge |

### Lines:

|              |              |
|--------------|--------------|
| E. 6-02-0813 | 8AN CPE Hose |
|--------------|--------------|

### Fittings:

|              |   |
|--------------|---|
| G. 6-02-0104 | 8AN to 3/8" Female EFI Quick Connect    |
| H. 6-02-0143 | 8AN to 5/16" Female EFI Quick Connect   |
| I. 6-02-0402 | 8AN ORB Male to 8AN Male Flare Adapter  |
| J. 6-02-0405 | 6AN ORB Male to 8AN Male Flare Adapter  |
| L. 6-02-0406 | 10AN ORB Male to 8AN Male Flare Adapter |
| M. 6-02-0805 | 8AN Female Swivel Straight Hose End     |
| N. 6-02-0806 | 8AN Female Swivel 45 Degree Hose End    |
| O. 6-02-0807 | 8AN Female Swivel 90 Degree Hose End    |
| P. 6-02-0823 | 8AN Female Swivel 120 Degree Hose End   |
| Q. 6-02-0706 | 8AN Male Flare Y-Block                  |



2020+ BMW G80 and A90 Supra X3 Plumbing Kit  
Part Number: 6-626