



Catalog #696490 and #696500
Russell Brake Line Kit
for 1999-2003 Ford F250/F350 Super Duty 4x4



INSTALLATION INSTRUCTIONS

Please study these instructions carefully before installing your new Brake Line Kit. If you have any questions or problems, please call our Technical Hotline at: 1-800-416-8628, 7:00 am to 5:00 pm, Monday - Friday, Pacific Standard Time or e-mail us at edelbrock.edelbrock.com.

INSTALLATION PROCEDURE

IMPORTANT NOTE: Do not allow the master cylinder to completely drain of brake fluid at any time during this process. Doing so may require removing the master cylinder from the vehicle for bench bleeding.

1. Replace factory hoses with the corresponding Russell Lines, routing them as shown in the photos.
2. The ABS wire and/or the axle vent hose must be re-attached to the new brake line using zip ties in order to keep them from being damaged.
3. Once installed, make sure that the new hoses are safely located during the full range of steering motion. The rear outer hoses are slightly re-routed from stock to reduce the risk of damage in an off-road situation.
4. Proceed to bleed the system.



Edelbrock Corporation, 2700 California Street, Torrance, CA 90503

Tech Line: 800-416-8628

Office: 310-781-2222

E-Mail: edelbrock@edelbrock.com