


2020+ BMW M3/M4 and Toyota Supra X3 Fuel Pump Module Plumbing Diagram - PTFE, OEM HPFP



Part Number Guide

Fuel System Components

A. 9-xxx-7080	X3 Module
B. 8-03-110-010K	DWFF110 Fuel Filter
C. 6-1000-FRB	DWR1000 AFPR
D. 6-01-G	Fuel Pressure Gauge

Lines:

E. 6-02-0862	8AN PTFE Hose
--------------	---------------

Fittings:

G. 6-02-0104	8AN to 3/8" Female EFI Quick Connect
H. 6-02-0143	8AN to 5/16" Female EFI Quick Connect
I. 6-02-0402	8AN ORB Male to 8AN Male Flare Adapter
J. 6-02-0405	6AN ORB Male to 8AN Male Flare Adapter
L. 6-02-0406	10AN ORB Male to 8AN Male Flare Adapter
M. 6-02-0854	8AN Female Swivel Straight Hose End
N. 6-02-0855	8AN Female Swivel 45 Degree Hose End
O. 6-02-0856	8AN Female Swivel 90 Degree Hose End
P. 6-02-0875	8AN Female Swivel 120 Degree Hose End



2020+ BMW G80 and A90 Supra X3 Plumbing Kit
Part Number: 6-627