

INTAKE MANIFOLD

NOTE: Best performance will be obtained by trimming the gasket ports to the steel valley pan ports. Thoroughly read these following instructions, then proceed.

1. Using a quick-drying adhesive cement the four gaskets to the steel pan. One pair for the upper face; one pair for the lower face. Allow adhesive to thoroughly dry.
2. Trim the gasket ports, using a sharp cutting tool, to match the ports of the steel valley pan ports, if required.
3. Prior to installing the gasket assembly to the engine, apply a 1/8" bead of silicone rubber sealant at the four corner joints of cylinder heads and crankcase.
4. Install the manifold. Torque to specifications.