

aFe Control Wheel Spacers Ford F150 15-25

KIT	Description
610-30T001-B	Wheel Spacer Kit 6x135, CB87.1, M14-1.5, 1.5"
610-30T002-B	Wheel Spacer Kit 6x135, CB87.1, M14-1.5, 2"

Procedure:

1. Safely lift the vehicle and remove wheel.
2. If needed, clean the hub center on the truck and hub bore on the wheel.
3. Place the aFe CONTROL spacer on the hub and ensure the spacer is fully seated.
4. Use supplied nuts to fasten spacer to original studs.
5. Tighten nuts in a star pattern using torque wrench set to **150 ft lbs**
6. If the OE studs protrude past the spacer, make sure your wheels have relief pockets to clear.
7. Install the wheel onto the new studs of the wheel spacer.
8. Tighten the wheel nuts with the OE nuts in a star pattern by hand first.
9. Spin the wheel and check for any noise or interference.
10. Tighten the lug nuts in a star pattern with a torque wrench set to **150 ft lbs**.

