


# 2020+ BMW M3/M4 and Toyota Supra X3 Fuel Pump Module Plumbing Diagram - PTFE, Port Injection



## Part Number Guide

Fuel System Components		Fittings:	
A. 9-xxx-7080	X3 Module	G. 6-02-0104	8AN to 3/8" Female EFI Quick Connect
B. 8-03-110-010K	DWFF110 Fuel Filter	H. 6-02-0143	8AN to 5/16" Female EFI Quick Connect
C. 6-1000-FRB	DWR1000 AFPR	I. 6-02-0402	8AN ORB Male to 8AN Male Flare Adapter
D. 6-01-G	Fuel Pressure Gauge	J. 6-02-0405	6AN ORB Male to 8AN Male Flare Adapter
		L. 6-02-0406	10AN ORB Male to 8AN Male Flare Adapter
Lines:		M. 6-02-0854	8AN Female Swivel Straight Hose End
E. 6-02-0862	8AN PTFE Hose	N. 6-02-0855	8AN Female Swivel 45 Degree Hose End
		O. 6-02-0856	8AN Female Swivel 90 Degree Hose End
		P. 6-02-0875	8AN Female Swivel 120 Degree Hose End
		Q. 6-02-0706	8AN Male Flare Y-Block

**DW**  
DEATSCHWERKS

2020+ BMW G80 and A90 Supra X3 Plumbing Kit  
Part Number: 6-627