

Included:

Aluminum Trigger Mount
4 x 6/32 screws and nuts
2 x 8 mm hex head Bolts
2 x flat washers

Installation:

- 1) Place the flat washers on the 8 mm bolts and insert into the mounting holes on the mount. **NOTE:** It can be difficult to install them once the Trigger is in place.
- 2) Use 6/32" screws/nuts to install the Trigger on the mount.
- 3) Install mount/Trigger onto the factory holes under the hood just behind the fuse box. See picture below for location detail.

Note: for 2002 to 2009 it may be necessary to flip the bracket over so the Trigger is higher in the engine bay.



NOTE: Route wires as required depending on installation requirements.