



---

**FEL-PRO INSTALLATION TIPS****HONDA SPEEDFIT OIL PAN FIT FORM**

Clean oil pan and engine block surfaces of all foreign material.

Check oil pan flanges for flatness – replace if severely distorted or damaged.

Apply a small dab of RTV sealant on the engine block front cover to engine block T-joint areas.

Align gasket on oil pan. Install oil pan with gasket on pan. Using one or two bolts through the pan and gasket may help to keep gasket in place during installation.

Torque bolts to OEM specifications following the OEM sequence.



---

**FEL-PRO INSTALLATION TIPS****HONDA SPEEDFIT OIL PAN FIT FORM**

Clean oil pan and engine block surfaces of all foreign material.

Check oil pan flanges for flatness – replace if severely distorted or damaged.

Apply a small dab of RTV sealant on the engine block front cover to engine block T-joint areas.

Align gasket on oil pan. Install oil pan with gasket on pan. Using one or two bolts through the pan and gasket may help to keep gasket in place during installation.

Torque bolts to OEM specifications following the OEM sequence.



---

**FEL-PRO INSTALLATION TIPS****HONDA SPEEDFIT OIL PAN FIT FORM**

Clean oil pan and engine block surfaces of all foreign material.

Check oil pan flanges for flatness – replace if severely distorted or damaged.

Apply a small dab of RTV sealant on the engine block front cover to engine block T-joint areas.

Align gasket on oil pan. Install oil pan with gasket on pan. Using one or two bolts through the pan and gasket may help to keep gasket in place during installation.

Torque bolts to OEM specifications following the OEM sequence.



---

**FEL-PRO INSTALLATION TIPS****HONDA SPEEDFIT OIL PAN FIT FORM**

Clean oil pan and engine block surfaces of all foreign material.

Check oil pan flanges for flatness – replace if severely distorted or damaged.

Apply a small dab of RTV sealant on the engine block front cover to engine block T-joint areas.

Align gasket on oil pan. Install oil pan with gasket on pan. Using one or two bolts through the pan and gasket may help to keep gasket in place during installation.

Torque bolts to OEM specifications following the OEM sequence.