



FEL-PRO INSTALLATION TIPS

Please clean the pan thoroughly, removing any large pieces of gasket or silicone material from the oil pan prior to gasket installation.

It is recommended that RTV Silicone sealer be applied to the gasket in the two crankshaft seal retainer joint areas, as well as applied to front cover engine block joint area

© 2018 Federal-Mogul Motorparts
Form No. I-2135 (Rev. 1/18)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Please clean the pan thoroughly, removing any large pieces of gasket or silicone material from the oil pan prior to gasket installation.

It is recommended that RTV Silicone sealer be applied to the gasket in the two crankshaft seal retainer joint areas, as well as applied to front cover engine block joint area

© 2018 Federal-Mogul Motorparts
Form No. I-2135 (Rev. 1/18)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Please clean the pan thoroughly, removing any large pieces of gasket or silicone material from the oil pan prior to gasket installation.

It is recommended that RTV Silicone sealer be applied to the gasket in the two crankshaft seal retainer joint areas, as well as applied to front cover engine block joint area

© 2018 Federal-Mogul Motorparts
Form No. I-2135 (Rev. 1/18)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Please clean the pan thoroughly, removing any large pieces of gasket or silicone material from the oil pan prior to gasket installation.

It is recommended that RTV Silicone sealer be applied to the gasket in the two crankshaft seal retainer joint areas, as well as applied to front cover engine block joint area

© 2018 Federal-Mogul Motorparts
Form No. I-2135 (Rev. 1/18)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Please clean the pan thoroughly, removing any large pieces of gasket or silicone material from the oil pan prior to gasket installation.

It is recommended that RTV Silicone sealer be applied to the gasket in the two crankshaft seal retainer joint areas, as well as applied to front cover engine block joint area

© 2018 Federal-Mogul Motorparts
Form No. I-2135 (Rev. 1/18)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Please clean the pan thoroughly, removing any large pieces of gasket or silicone material from the oil pan prior to gasket installation.

It is recommended that RTV Silicone sealer be applied to the gasket in the two crankshaft seal retainer joint areas, as well as applied to front cover engine block joint area

© 2018 Federal-Mogul Motorparts
Form No. I-2135 (Rev. 1/18)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Please clean the pan thoroughly, removing any large pieces of gasket or silicone material from the oil pan prior to gasket installation.

It is recommended that RTV Silicone sealer be applied to the gasket in the two crankshaft seal retainer joint areas, as well as applied to front cover engine block joint area

© 2018 Federal-Mogul Motorparts
Form No. I-2135 (Rev. 1/18)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Please clean the pan thoroughly, removing any large pieces of gasket or silicone material from the oil pan prior to gasket installation.

It is recommended that RTV Silicone sealer be applied to the gasket in the two crankshaft seal retainer joint areas, as well as applied to front cover engine block joint area

© 2018 Federal-Mogul Motorparts
Form No. I-2135 (Rev. 1/18)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Please clean the pan thoroughly, removing any large pieces of gasket or silicone material from the oil pan prior to gasket installation.

It is recommended that RTV Silicone sealer be applied to the gasket in the two crankshaft seal retainer joint areas, as well as applied to front cover engine block joint area

© 2018 Federal-Mogul Motorparts
Form No. I-2135 (Rev. 1/18)

Printed in U.S.A.