



## CARE GUIDE: THE AWE S-FLO FILTER

### CARE ROUTINE

The S-FLO filter is a re-usable air filter that can be cleaned when dirty and put back into service. Please inspect the air filter element every 25,000 miles for integrity. Clean every 50,000 miles under normal operating conditions. For performance applications, it is recommended to clean the filter every 10,000 miles to ensure optimum performance.

Any questions or comments,  
please do not hesitate to contact us:

**AWE**  
[SUPPORT FORM](#)

# **CLEANING GUIDE**

To clean your AWE S-FLO air filter:

## **REMOVAL**

Carefully take the filter out of your AWE intake, ensuring no loose debris falls into the open intake.

## **TAP OFF HEAVY STUFF**

Hold the filter over a trash can and gently tap the rubber base.

Getting as much loose dust, dirt, and bugs out before introducing water prevents the debris from turning into mud and clogging the filter surface.

## **RINSE FROM INSIDE OUT**

Hold the filter under a faucet or a gentle garden hose stream.

Direct the water through the clean side (inside) of the filter so it flushes the dirt out toward the dirty side.

Rinse until the water running through the filter is completely clear.

## **AIR DRY COMPLETELY**

Shake off the excess water.

Set the filter in a clean, well-ventilated area to dry. Because synthetic media holds onto water, this will likely take several hours or overnight.

## **REINSTALL**

Once the filter is 100% dry to the touch, reinstall it and tighten your clamps.