

Clean Rocker Cover Gasket Surface of all foreign materials. You may wish to use a degreaser, such as Cleaner/Degreaser.

Molded Rubber Gasket(s) are to be installed dry.

Straighten Cover Flanges, replace cover if it is excessively distorted.

Install Gasket onto cylinder head with the directional stamp facing up, towards the pushrod side of the head.

IMPORTANT: Check for interference between the pushrods and the gasket. The steel carrier in the gasket is cut back at the pushrod locations. Trim rubber carefully with a knife for additional pushrod clearance.

Install Cover onto engine; avoid over-torquing. When using sheet metal covers, the use of load spread washers is recommended.

WARNING: This gasket was designed for racing applications. Using this gasket on stock type engines with exhaust crossovers and EGR valves is not recommended.

©1998 Fel-Pro Incorporated

Printed in U.S.A

Form No. I-1981 (Rev. 3/98)