

WATER PUMP GASKET

INSTALL "O" RING SEAL into the groove of the water pump casting.



© 2000 Federal-Mogul Corporation Form No. I-1390 (Rev. 02/93) Printed in U.S.A.



WATER PUMP GASKET

INSTALL "O" RING SEAL into the groove of the water pump casting.



© 2000 Federal-Mogul Corporation Form No. I-1390 (Rev. 02/93) Printed in U.S.A.



WATER PUMP GASKET

INSTALL "O" RING SEAL into the groove of the water pump casting.





WATER PUMP GASKET

INSTALL "O" RING SEAL into the groove of the water pump casting.



© 2000 Federal-Mogul Corporation Form No. I-1390 (Rev. 02/93) Printed in U.S.A.



WATER PUMP GASKET

INSTALL "O" RING SEAL into the groove of the water pump casting.



© 2000 Federal-Mogul Corporation Form No. I-1390 (Rev. 02/93) Printed in U.S.A.



WATER PUMP GASKET

INSTALL "O" RING SEAL into the groove of the water pump casting.



© 2000 Federal-Mogul Corporation Form No. I-1390 (Rev. 02/93) Printed in U.S.A.



WATER PUMP GASKET

INSTALL "O" RING SEAL into the groove of the water pump casting.



© 2000 Federal-Mogul Corporation Form No. I-1390 (Rev. 02/93) Printed in U.S.A.



WATER PUMP GASKET

INSTALL "O" RING SEAL into the groove of the water pump casting.



WATER PUMP GASKET

INSTALL "O" RING SEAL into the groove of the water pump casting.

FEL-PRO INSTALLATION TIPS

