

Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

## **EXHAUST MANIFOLD GASKET**

This set contains 3 exhaust manifold gaskets. identify and install as indicated.

**CLEAN MATING SURFACES** of all foreign material including old gaskets and oil. You may wish to use a degreaser.

**CHECK EXHAUST MANIFOLD** for flatness with a straight edge. resurface or replace if severly corroded or distorted.



-continued-

**CLEAN ALL THREADS** by using a wire brush for bolts and studs, tap all bolt holes and stud nuts. Apply a high temperature anti-seize lubricant to the bolts and stud threads.

ATTACH AND ALIGN GASKET TO CYLINDER HEAD. Install gasket that is fiber faced (on both sides) to the left side of the engine between the cylinder head and the inner heat stove. The 2 other gaskets are identical, steel faced on one side and fiber on the other. Install steel faced sides toward each manifold.

**REINSTALL MANIFOLD TO ENGINE.** Torque securely to OEM specifications.

**TEST RUN ENGINE.** Check all mating areas thoroughly to determine that all seals hold during operation.



**CLEAN ALL THREADS** by using a wire brush for bolts and studs, tap all bolt holes and stud nuts. Apply a high temperature anti-seize lubricant to the bolts and stud threads.

ATTACH AND ALIGN GASKET TO CYLINDER HEAD. Install gasket that is fiber faced (on both sides) to the left side of the engine between the cylinder head and the inner heat stove. The 2 other gaskets are identical, steel faced on one side and fiber on the other. Install steel faced sides toward each manifold.

**REINSTALL MANIFOLD TO ENGINE.** Torque securely to OEM specifications.

**TEST RUN ENGINE.** Check all mating areas thoroughly to determine that all seals hold during operation.



© 2000 Federal-Mogul Corporation Form No. I-854 (Rev. 03/92) Printed in U.S.A.



Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

## **EXHAUST MANIFOLD GASKET**

This set contains 3 exhaust manifold gaskets. identify and install as indicated.

**CLEAN MATING SURFACES** of all foreign material including old gaskets and oil. You may wish to use a degreaser.

**CHECK EXHAUST MANIFOLD** for flatness with a straight edge. resurface or replace if severly corroded or distorted.





Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

## **EXHAUST MANIFOLD GASKET**

This set contains 3 exhaust manifold gaskets. identify and install as indicated.

**CLEAN MATING SURFACES** of all foreign material including old gaskets and oil. You may wish to use a degreaser.

**CHECK EXHAUST MANIFOLD** for flatness with a straight edge. resurface or replace if severly corroded or distorted.



-continued-

**CLEAN ALL THREADS** by using a wire brush for bolts and studs, tap all bolt holes and stud nuts. Apply a high temperature anti-seize lubricant to the bolts and stud threads.

ATTACH AND ALIGN GASKET TO CYLINDER HEAD. Install gasket that is fiber faced (on both sides) to the left side of the engine between the cylinder head and the inner heat stove. The 2 other gaskets are identical, steel faced on one side and fiber on the other. Install steel faced sides toward each manifold.

**REINSTALL MANIFOLD TO ENGINE.** Torque securely to OEM specifications.

**TEST RUN ENGINE.** Check all mating areas thoroughly to determine that all seals hold during operation.



**CLEAN ALL THREADS** by using a wire brush for bolts and studs, tap all bolt holes and stud nuts. Apply a high temperature anti-seize lubricant to the bolts and stud threads.

ATTACH AND ALIGN GASKET TO CYLINDER HEAD. Install gasket that is fiber faced (on both sides) to the left side of the engine between the cylinder head and the inner heat stove. The 2 other gaskets are identical, steel faced on one side and fiber on the other. Install steel faced sides toward each manifold.

**REINSTALL MANIFOLD TO ENGINE.** Torque securely to OEM specifications.

**TEST RUN ENGINE.** Check all mating areas thoroughly to determine that all seals hold during operation.



© 2000 Federal-Mogul Corporation Form No. I-854 (Rev. 03/92) Printed in U.S.A.



Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

## **EXHAUST MANIFOLD GASKET**

This set contains 3 exhaust manifold gaskets. identify and install as indicated.

**CLEAN MATING SURFACES** of all foreign material including old gaskets and oil. You may wish to use a degreaser.

**CHECK EXHAUST MANIFOLD** for flatness with a straight edge. resurface or replace if severly corroded or distorted.

