

INSTALLATION GUIDE:
AWE DV ADAPTER KIT FOR 2019+ RS3 AND TTRS

For up-to-date fitment information, please visit the product page on AWE-Tuning.com.

THIS GUIDE IS INTENDED FOR THE FOLLOWING PART NUMBERS:

2660-11020 AWE DV Adapter Kit for 2019+ Models

Welcome to the AWE family, and congratulations on your purchase of the AWE DV Adapter Kit for the Audi RS3 and TTRS.

Exquisite build quality and craftsmanship, coupled with industry leading performance, distinguish this DV Adaptor Kit from all others.

*For up to the minute fitment information, be sure to visit the AWE website. As always, AWE Performance Specialists are standing by for any questions, right here.

Copyright 2019, AWE. No part of this document may be reused or duplicated without the express permission of AWE/Secor Ltd. All rights reserved. Rev1.1

PARTS LIST

INSPECT ALL PARTS PRIOR TO DISASSEMBLY OF VEHICLE; IF DAMAGED OR MISSING, PLEASE CONTACT THE PLACE OF PURCHASE IMMEDIATELY.

AWE DV Adapter Kit for 2019+ Models

Letter	QTY	Description	Part Number
A	1	2019+ 2.5T DV adaptor	150006
B	1	Oil-resistant soft buna-n O-rings, 1/16 fractional width	2418T121
C	1	Oil-resistant soft buna-n O-rings, 3/32 fractional width	2418T145
D	2	Worm-drive clamps, 5/16" band width, 24-38mm clamp ID	5388K24
F	1	1" ID black high temp reinforced silicone heater hose - 8.75”	HTHH-100-BLK



Copyright 2019, AWE. No part of this document may be reused or duplicated without the express permission of AWE/Secor Ltd. All rights reserved. Rev1.1

NOTE: Always refer to the manufacturer's service manual for precise torque specifications on all OEM fasteners.

CAUTION: The engine may be **VERY HOT —** allow adequate time for the system to cool down before disassembly. Severe burns and injury will occur if skin comes into contact with a hot components.

STEP 1

The installation of the AWE diverter valve requires you to remove the OEM diverter valve hose, shown in **Figure 1-1** and **1-2**.






FIGURE 1-1



FIGURE 1-2

STEP 2

Remove the 2 bolts on the engine side of the OEM hose, shown in **Figure 2-1.** This will allow the diverter valve hose to be removed with the OEM intake, shown in **Figure 2-2**.

Note: These 2 bolts will be reused in the install of your AWE diverter valve.


FIGURE 2-1


FIGURE 2-2

Copyright 2019, AWE. No part of this document may be reused or duplicated without the express permission of AWE/Secor Ltd. All rights reserved. Rev1.1

STEP 3

Gather the AWE diverter valve adapter and the 2 O-rings provided, and install these onto the diverter valve, as shown in **Figure 3-1** and **3-2**.




FIGURE 3-1




FIGURE 3-2

STEP 4

With the O-rings installed onto the adapter, install it into the OEM location, as shown in **Figure 4**.




FIGURE 4

STEP 5

Install the bolts removed earlier from the OEM hose into the AWE diverter valve, as shown in **Figure 5**.





FIGURE 5

Copyright 2019, AWE. No part of this document may be reused or duplicated without the express permission of AWE/Secor Ltd. All rights reserved. Rev1.1

STEP 6

Install the provided hose and 2 hose clamps onto the diverter valve and AWE carbon intake, as shown in **Figure 6-1** and **6-2**.


FIGURE 6-1




FIGURE 6-2

STEP 7

Following your AWE carbon fiber intake install instructions to complete the install of your intake.




FIGURE 7

ENJOY!

Copyright 2019, AWE. No part of this document may be reused or duplicated without the express permission of AWE/Secor Ltd. All rights reserved. Rev1.1

TROUBLESHOOTING

Issue	Solution
Wrong or missing parts	Double check the parts list for your system and compare them with what you received. Fill out our contact form, found below and let us know what parts you need.

Any questions or comments,
please do not hesitate to contact us:

AWE

215-658-1670
CONTACT FORM

WARRANTY

Up-to-date warranty information is found **HERE**.

Copyright 2019, AWE. No part of this document may be reused or duplicated without the express permission of AWE/Secor Ltd. All rights reserved. Rev1.1