



Silver Bullet®

Throttle Body Spacer

PN 46-37007

INSTALLATION INSTRUCTIONS


Important!

Please verify the Parts List and read all instruction steps before you begin installation.

Year	Make	Model	Engine
2016-2024	Honda	Civic	I4-2.0L
2023-2026	Honda	HR-V	I4-2.0L

1. Remove the intake tube from the throttle body.
2. Unplug the throttle body connector by pressing the tab and gently pulling it free. Using a small flat-blade screwdriver, remove the plastic connector cover for clearance.
3. Using a 12 mm socket and driver, remove the four (4) screws and the two (2) rear brackets securing the throttle body to the intake manifold. (Note: These factory screws will not be reused in this installation. However, you may want to keep them in case the spacer is ever removed and the vehicle is returned to stock.)
4. The coolant hoses connected to the throttle body do not need to be removed. Simply move the throttle body out of the way.
5. Ensure the factory O-ring seal on the intake manifold is in place and free of debris.
6. Install the provided O-ring seal on the aFe **Silver Bullet** throttle body spacer.
7. Position the aFe **Silver Bullet** throttle body spacer between the intake manifold and the throttle body with the "Air In" side facing the throttle body and the word "Top" facing upward.
8. Install the throttle body using the provided hardware and the two (2) factory rear brackets removed in Step 3: place one (1) lock washer and one (1) flat washer onto each of the four (4) M8 x 80 mm screws. Secure the throttle body and spacer to the intake manifold using a 13 mm socket and driver. Tighten the screws to 22 N·m (16 ft-lb).
9. Reinstall the intake tube removed in Step 1 and tighten all connections.

Your installation is now complete! Make sure to retighten all bolts and clamps after 100 miles of driving.



Step 1




Step 2



Steps 3-5



Steps 6-7



Steps 8-9

Parts List

- 1 aFe **Silver Bullet** Throttle Body Spacer
- 1 O-Ring Seal
- 4 M8 x 80 mm Hex Head Screw
- 4 M8 Flat Washers
- 4 M8 Lock Washers

Tools Needed

- Socket Driver
- 12 mm socket
- 13 mm socket
- Small Flat-Blade Screwdriver

advanced FLOW engineering, Inc.

Corona, CA

WWW.aFePOWER.COM