



INSTALLATION GUIDE

PART NUMBER: 5489
FRONT ANTI-SWAY BAR
CHEVROLET BEL-AIR | 1955-1957

300 W. PONTIAC WAY. CLOVIS, CA 93612
PHONE: 800-445-3767 | EMAIL: INFO@BELLTECH.COM

THANK YOU

Thank you for choosing our high quality Belltech product. We have spent a great deal of time developing our line of products so that you will receive maximum performance with minimal difficulty during installation. Soon your vehicle will be on the road looking and feeling much improved.

Please take a moment to read all instructions and warnings prior to installation of your new Belltech product and before operating your vehicle. If you have any questions or concerns regarding any step in the installation process, please do not hesitate to call or email our customer support specialists who are trained to help you through any portion of this process.

Before You Begin:

It is of the utmost importance that you confirm all the components listed on the parts list are in the kit. You can find this list located on the last page(s) of your instructions. Do not begin installation if any part is missing. Instead, please call our Belltech customer service specialists.

Belltech Customer Support:

Phone: 1-800-445-3767

Email: info@belltech.com

Safety Information:

Warning: Do not work under a vehicle supported only by a jack. Place support stands securely under the vehicle in the manufacturer's specified locations unless otherwise instructed.

Proper use of safety equipment and eye/face/hand protection is necessary when performing any of the following instructions.

We strive for an exceptional experience for all our valued customers. If for any reason you need assistance with your Belltech products, please do not return the product to the store you purchased from, but rather call our dedicated customer service experts, from 7am to 5pm PST.

We recommend that a qualified mechanic, in a properly equipped facility, perform this installation.

It is very helpful to have an assistant available during installation.

Before Driving Your Vehicle:

It is important to double check all brake hoses, cables, and other components to be sure there is no interference. You must also check for wheel/tire to chassis/body interference. If any issues are found, review your installation instructions to be sure no steps were missed, and any problems are corrected.

Make sure your vehicle is aligned immediately following installation.

Check all hardware and torque at intervals for the first 10, 100, and 1000 miles.

Some of Belltech's products are designed to improve your vehicle's off-road performance. Leveling/lifting your vehicle may result in an altered center of gravity. It is crucial to use extreme care when operating your vehicle to prevent rollover and/or loss of control.

Any changes in your vehicle's suspension may result in transformed handleability. Please test-drive your vehicle in a remote location so you can become accustomed to the revised driving characteristics.

Perform headlight check and adjustment.

Failure to drive any modified vehicle in a safe manner may result in harm or death.

Never operate your modified vehicle under the influence of drugs, alcohol, or lack of adequate sleep.

Always wear your seatbelt.



DIFFICULTY:



INSTALLATION TIME: 1 Hour

RECOMMENDED TOOLS:

- Properly rated floor jack
- Support stands
- Wheel chocks
- Metric socket wrench set
- Metric wrench set
- Drill with drill bit set
- Center punch
- Safety glasses
- Marker or paint pen
- Torque wrench rated up to 100 ft lbs.

JACKING, SUPPORTING, AND PREPARING THE VEHICLE

1. Park your vehicle on a smooth, level, concrete, or seasoned asphalt surface.
2. Block the rear wheels of the vehicle using wheel chocks. Make sure the vehicle's transmission is in "PARK" (automatic) or first gear (manual).
3. Activate the parking brake.
4. Lift the front of the vehicle off the ground using a properly rated floor jack. Lift the vehicle so the front tires are approximately 6-8 inches off the ground.
5. Place support stands rated for the vehicle's weight. The stands must be positioned in the factory specified locations. (Refer to the owner's manual). Prior to lowering the vehicle onto stands, make sure the support stands will contact the chassis. It is very important that the vehicle is properly supported to prevent any harm to oneself or to the vehicle.
6. Lower the vehicle slowly onto the stands.



Technician reminder:

Never work under a vehicle supported only by a jack. It is necessary to place support stands securely under the vehicle in the manufacturer's specified locations unless otherwise instructed.

BELLTECH SWAY BAR INSTALLATION

7. Some models may have a front sway bar installed. If so, use the existing end link and bushing bracket holes to attach the new Belltech hardware. If your vehicle does not have an installed front sway bar, proceed with the following instructions.
8. Place and hold the sway bar arms on top of each lower control arm and position the sway bar in the center of the vehicle.



9. Use the ends of the sway bar to mark the lower control arms where new holes will be drilled for the end links.




10. After the holes have been marked, measure the distance between the end link hole centers of the sway bar and compare the distance between the two marked points on the control arms. They must be the same.
11. Use a center punch to mark each hole and proceed to drill both holes to 3/8" diameter.



BELLTECH SWAY BAR INSTALLATION CONTINUED

12. The end links must be assembled through the lower control arms and the ends of the Belltech sway bar as shown in the diagram below.



13. Assemble and fasten the end link assemblies through the ends of the Belltech sway bar and lower control arms. Tighten the end link nuts to the point where the rubber grommets do not rotate by hand.





14. With the end links attached to the control arms, place the supplied pivot bushings and pivot bushing brackets onto the sway bar without lubrication. Position them directly under the frame. Use the brackets to mark the position of the four mounting holes. Center punch the marked locations and drill four 3/8" diameter holes.



15. Remove the brackets and bushings off the sway bar. Thoroughly lubricate the inside of the supplied pivot bushings using the grease packet included with the kit.
16. Place the bushings on both sides of the Belltech sway bar, where they were previously located, rotate the bushings slightly to spread the lubricant evenly. Place the bushing brackets over the bushings.
17. The bushing brackets will be fastened to the frame with the supplied support plates, 3/8"-16 X 1-1/2" bolts, 3/8" washers, and Nyloc nuts.

BELLTECH SWAY BAR INSTALLATION CONTINUED

18. Place one support plate between the bushing and the frame. Place the second support plate on top of the frame.



19. Fasten with the bolt and a washer on the bolt head. Use another washer and the Nyloc nut on the opposite end. Torque to 25 ft lbs.



20. Check brake hoses and other components for any possible interference after the vehicle is lowered to the ground.




FINALIZING THE INSTALLATION

21. Lift the vehicle and remove the support stands.
22. Carefully lower the vehicle onto flat ground.
23. Check that all components and fasteners have been properly installed and torqued.
24. Read and perform all tasks in the “Before Driving Your Vehicle” section of page 1 of your instructions.

THANK YOU FOR CHOOSING BELLTECH.

You are now a part of the Belltech family and we are eager to catch a glimpse of your newly modified vehicle. Give us a shout out and let us know how much you love our product. Don't forget, we offer other Belltech related merchandise for you and your vehicle on our website www.belltech.com



belltechsuspension



Belltech Suspension



@belltechsuspension



@belltechsuspension

If you have any questions, concerns, or warranty related issues regarding your Belltech product, please call or email our experienced customer service specialists.

Belltech Customer Support:

Phone: 1-800-445-3767

Email: info@belltech.com

KIT CONTENTS



SWAY BAR KIT		
Part number	Description	Qty
5489-300	1-1/4" FRONT SWAY BAR	1
5489-777	HARDWARE KIT	1

HARDWARE KIT		
Part number	Description	Qty
110255	3/8"-16 NYLOC NUT	6
112114	3/8"-16 X 3-1/2" BOLT	2
112098	3/8"-16 X 1-1/2" BOLT	4
110625	3/8" WASHER	8
112502	CUP WASHER	4
113000	END LINK GROMMET	6
114038-95	BUSHING SUPPORT PLATE	4
114026-95	PIVOT BUSHING BRACKET	2
113095	1-1/4" PIVOT BUSHING	2
55000-10	WHITE LITHIUM GREASE	1



KW automotive North America, Inc.

300 W. Pontiac Way

Clovis, CA 93612

Phone: +1-559-875-0222

Toll Free: 1-800-445-3767

belltech.com