



# INSTALLATION INSTRUCTIONS

Not legal for sale or use in California on any pollution controlled motor vehicle.

## 70-1563

## JEEP / DODGE

### 2011-21 Grand Cherokee

### V8-5.7L


### 2011-26 Durango

### V8-5.7L

#### TOOLS NEEDED:

- 4mm Allen Wrench
- Flathead screwdriver
- Extension
- Ratchet
- 8mm socket
- 13/16" wrench
- Pliers
- 10mm Socket
- 5/16" Socket / Nut Driver

**NOTE:** This kit is not compatible with SRT Hood.



#### PARTS LIST:

Description	Qty.	Part #	Description	Qty.	Part #	Description	Qty.	Part #
A HOSE CLAMP; #56 BLK	2	08620KA	E GROMMET; 1"OD, 1/2"ID	1	08064	I CLIP; FILTER ORANGE	1	088223
B HOSE; HUMP 3.5"ID X 2.5"L	1	08699	F VENT; 90 DEG, 1/2" HOSE	1	08110FK	J CLIP; FILTER RED	1	088222
C HOSE; 1/2"ID X 16"L	1	5-5016	G HOSE CLAMP; #72 BLK	1	08671KA	K AIR BOX	1	087637
D TUBE; 3.5"OD X 23"L	1	27693C	H AIR FILTER	1	RU-5343	L CLIP; RETAINER	2	KITRETCLIP02

**If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.**

**NOTE: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE INTAKE TUBE, THROTTLE BODY AND ENGINE.**

#### TO START:

1. Turn off the ignition and disconnect the negative battery cable.  
**NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is reconnected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicles anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicles anti-theft code.**



2. Lift up the engine cover to dislodge it from the mounting grommets and remove it from the vehicle.




3. Remove the intake plenum mounting bolt shown and loosen the intake tube hose clamp.



4. Disconnect the inlet air temperature air sensor electrical connection.



5. Disconnect the crankcase vent hose from the port on the valve cover.



6. Release the two upper airbox retaining clips.



7. Remove the upper airbox and intake tube assembly.



8. Unhook the sealing trim from the fresh air intake scoop and keep clip.



9. Lift up the lower airbox to dislodge it from the mounting grommets and then remove the lower airbox from the vehicle. Some vehicles may have a power steering line attached to the air box than will need to be unhooked.

**NOTE: K&N Engineering, Inc., recommends that customers do not discard factory air intake.**



10. Remove three factory airbox mounting grommets from the lower airbox.




11. Release the locking tab and then remove the inlet air temperature sensor from the factory intake tube by twisting counter clockwise.

**NOTE: The inlet air temperature sensor is very fragile; take care to avoid damage while handling the sensor.**



12. Install the 3 grommets from step 10 into the new K&N airbox.



13. Attach the filter clips to the pleats on the air filter align and push down. Driver side filters, place orange clip on top and red on bottom.



14. Install the air filter into the K&N airbox.



15. Install the airbox assembly into the vehicle and position to the original airbox mounting studs.



16. Secure the front of the airbox using provided push clips.



17. Install the hose with clamps to the throttle body and tighten clamp on throttle body only. Tighten clamps using 5/16" socket or nut driver.

**Note: Do not over tighten clamps.**



18. With provided grommet, attach to the hole on the intake tube. Install the temperature sensor into the grommet.

**NOTE: Remove the o-ring for easier installation.**



19. Install the provided vent fitting into the K&N intake tube.

**NOTE: The quick connect fitting utilizes 3/8npt threads, thread the fitting in by hand and then tighten one revolution.**



20. Install the intake tube and position to filter and throttle body. Once adjusted properly, tighten all clamps. Tighten clamps using 5/16" socket or nut driver.

**Note: Do not over tighten clamps.**



21. Install the provided K&N decal to the intake tube at desired position.



22. With provided hose, connect the crank case line to the engine and barbed fitting on intake tube. **NOTE: Use silicone spray lubricant to assist installing the hose onto the barbed fitting installed into the K&N intake tube.**



23. Connect the inlet air temperature sensor as shown.



24. Re-install the engine cover.



25. Reconnect the vehicle's negative battery cable. Double check to make sure everything is tight and properly positioned before starting the vehicle.

26. **K&N AIR FILTER MONITOR LIGHT:** Some vehicles are equipped with a "Air Filter Monitor" system that will send a message to the instrument cluster indicating that the air filter needs to be replaced. This system is calibrated for the OEM intake system and air filter and will not be accurate when K&N products are in use. Always refer to [WWW.KNFILTERS.COM](http://WWW.KNFILTERS.COM) for K&N air filter service procedures. The "Air Filter Monitor" system must be disabled to prevent the monitor from setting on and causing a factory dealership visit to reset the system. Follow the "Air Filter Monitor" system procedure listed in the factory owners manual.

27. It will be necessary for all K&N® high flow intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void warranty.

#### ROAD TESTING:

1. Start the engine with the transmission in neutral or park, and the parking brake engaged. Listen for air leaks or odd noises. For air leaks secure hoses and connections. For odd noises, find cause and repair before proceeding. This kit will function identically to the factory system except for being louder and much more responsive.

2. Test drive the vehicle. Listen for odd noises or rattles and fix as necessary.

3. If road test is fine, you can now enjoy the added power and performance from your kit.

4. K&N Engineering, Inc., requires cleaning the intake system's air filter element every 50,000 miles. When used in dusty or off-road environments, our filters will require cleaning more often. We recommend that you visually inspect your filter once every 25,000 miles to determine if the screen is still visible. When the screen is no longer visible some place on the filter element, it is time to clean it. To clean, purchase our Synthetic Filter Cleaner, part number 99-0624 and follow the easy instructions.