





Please study these instructions carefully before installing your new Brake Line Kit. If you have any questions or problems, please call our Technical Hotline at: 1-800-416-8628, 7:00 am to 5:00 pm, Monday - Friday, Pacific Standard Time or e-mail us at [edelbrock.edelbrock.com](mailto:edelbrock.edelbrock.com).

#### INSTALLATION PROCEDURE

**IMPORTANT NOTE:** Do not allow the master cylinder to completely drain of brake fluid at any time during this process. Doing so may require removing the master cylinder from the vehicle for bench bleeding.

1. Disconnect the brake hose bracket from the top of the spindle. This bracket will not be re-used.
2. Disconnect the factory brake hose at both ends, and replace it with one of the new Russell lines marked "Front" using the new crush washers supplied. The banjo is installed on the caliper so that the hose is directed up and over the top of the caliper.
3. Attach the new brake line and ABS sensor wire to the top of the spindle where the original line was mounted, using the cushion clamps provided. Hose routing is shown in the photos below.  
**NOTE:** There are two holes on the top of the spindle where the brake lines mount. On the passenger side, only the rear-most hole is threaded to accept the bolt. For best results, tap the forward-most hole to 6MM x 1.0 thread, using that hole to mount the passenger side brake line and ABS wire.
4. Once installed, be sure to check hose clearance throughout the full range of steering motion.
5. Now replace the rear hose with the new Russell line marked "Rear Center", "Rear Right" and "Rear Left" duplicating the factory routing.
6. Double check that all fittings are tight and proceed to bleed the brake system.



Edelbrock Corporation  
2700 California St.  
Torrance, CA 90503  
Tech Line: 800-416-8628  
Office: 310-781-2222  
E-Mail: [edelbrock@edelbrock.com](mailto:edelbrock@edelbrock.com)